
# **DAM6081 User's Manual**



W Beijing ART Technology Development Co., Ltd.

# **DAM6081**

#### • Terminal Distribution



### Feature

4-channel High-speed Counter/Frequency Module

- ▶ 4-channel 32-bit counter, the max count value is 294967295
- Input Frequency:

5~1MHz max (frequency mode)

1MHZ max (counter mode)

- Mode: count (double-pulse, single-pulse) frequency
- Input signal can be set to isolated or non-isolated (jumper selectable)
- Isolation Voltage: 2500Vrms
- Input Voltage:

Isolation: logic level 0: +1V (MAX)

logic level 1:  $+10V \sim +30V$ 


Non-isolated: logic level 0: 0V ~+ 0.8V

logic level 1:  $2.3V \sim +5V$ 


- 4-channel open-collector output, maximum load 30V, 100mA
- Power Consumption: 1.5W




**Isolation Selection** 




#### Non-isolated Selection





Non-isolated Wiring (B signal is the same as A signal)



Output Signal Wiring (the maximum load current is 100mA)

There are three working mode (software selection), including the double-pulse count mode, single-pulse count mode, and the frequency mode.

1. Double-pulse Count Mode

The frequency of the count mode up to 1MHz, the voltage range shown as the parameters. When in adding count mode, only connect with A signal, in reduction count, only connect with B signal. When there are both A signal and B signal, the encoder output frequency of the A and B are the same, so the module does not count. If connect with the signal generator, the frequency of the two signal generators are different, so the count value is the difference of A frequency and the B frequency.

#### 2. Single-pulse Count Mode

The frequency of the count mode up to 1MHz, the voltage range shown as the parameters. B signal control the count direction. In isolation status, there are two logic level of B signal, logic level 0 (adding count), and logic level 1(reduction count). In no-isolation status, there are also two logic level of B signal, logic level 1 (adding count), and logic level 0 (reduction count).

# Note: in the isolated state and non-isolated state, the voltage of the B signal is different.

## 3. Frequency Mode

In this mode, only connect A signal, the frequency range is 5~1MHz.

# ◆ Address Configuration Table

Address (A8~A1)	Operating	Direction
x00	D[1:0]counter0 mode control word	Can be read back
	D[3:2] counter1 mode control word	
	D[5:4] counter2 mode control word	
	D[7:6] counter3 mode control word	
	Mode control word direction	
	00: single-pulse mode	
	01: double-pulse mode	
	10: frequency mode	
x01	D[0] effective, channel 0 measurement	Can be read back
	frequency timer length	
	= 0 measurement frequency timer 10ms	
	= 1 measurement frequency timer 1s	
x02	D[0] effective, channel 1 measurement	Can be read back
	frequency timer length	
	= 0 measurement frequency timer 10ms	
	= 1 measurement frequency timer 1s	
x03	D[0] effective, channel 2 measurement	Can be read back
	frequency timer length	
	= 0 measurement frequency timer 10ms	
	= 1 measurement frequency timer 1s	
x04	D[0] effective, channel 3 measurement	Can be read back
	frequency timer length	
	= 0 measurement frequency timer 10ms	
	= 1 measurement frequency timer 1s	
x05	Counter 0 initial value setting CNT0[31:0]	Can be read back
x06	Counter 0 initial value setting CNT0[23:16]	Can be read back
x07	Counter 0 initial value setting CNT0[15:8]	Can be read back
x08	Counter 0 initial value setting CNT0[7:0]	Can be read back
x09	Counter 1 initial value setting CNT1[31:0]	Can be read back
x0A	Counter 1 initial value setting CNT1[23:16]	Can be read back
x0B	Counter 1 initial value setting CNT1[15:8]	Can be read back
x0C	Counter 1 initial value setting CNT1[7:0]	Can be read back
x0D	Counter2 initial value setting CNT2[31:0]	Can be read back
x0E	Counter 2 initial value setting CNT2[23:16]	Can be read back
x0F	Counter 2 initial value setting CNT2[15:8]	Can be read back
x10	Counter 2 initial value setting CNT2[7:0]	Can be read back
x11	Counter 3 initial value setting CNT3[31:0]	Can be read back
x12	Counter 3 initial value setting CNT3[23:16]	Can be read back
x13	Counter 3 initial value setting CNT3[15:8]	Can be read back
x14	Counter 3 initial value setting CNT3[7:0]	Can be read back
x15	Counter 0 upper limit setting	Can be read back
	CNT0[15:0]CNT0_H_VAL[31:0]	
x16	Counter 0 upper limit setting	Can be read back
	CNT0_H_VAL [23:16]	
x17	Counter 0 upper limit setting	Can be read back
	CNT0_H_VAL [15:8]	
x18	Counter 0 upper limit setting	Can be read back
	CNT0_H_VAL [7:0]	
x19	Counter 1 upper limit setting	Can be read back
	CNT1_H_VAL[31:0]	

x1A       x1B       x1C       x1C       x1D       x1E       x1F       x20       x21       x22       x23	Counter 1 upper limit setting CNT1_H_VAL [23:16] Counter 1 upper limit setting CNT1_H_VAL [15:8] Counter 1 upper limit setting CNT1_H_VAL [7:0] Counter 2 upper limit setting CNT2_H_VAL [31:0] Counter 2 upper limit setting CNT2_H_VAL [23:16] Counter 2 upper limit setting CNT2_H_VAL [15:8] Counter 2 upper limit setting CNT2_H_VAL [7:0] Counter 3 upper limit setting CNT3_H_VAL [31:0] Counter 3 upper limit setting CNT3_H_VAL [23:16] Counter 3 upper limit setting	Can be read back Can be read back
x1C       x1D       x1E       x1F       x20       x21       x22       x23	Counter 1 upper limit setting <u>CNT1_H_VAL [15:8]</u> Counter 1 upper limit setting <u>CNT1_H_VAL [7:0]</u> Counter 2 upper limit setting <u>CNT2_H_VAL [31:0]</u> Counter 2 upper limit setting <u>CNT2_H_VAL [23:16]</u> Counter 2 upper limit setting <u>CNT2_H_VAL [15:8]</u> Counter 2 upper limit setting <u>CNT2_H_VAL [7:0]</u> Counter 3 upper limit setting <u>CNT3_H_VAL [31:0]</u> Counter 3 upper limit setting <u>CNT3_H_VAL [23:16]</u>	Can be read back
x1D       x1E       x1F       x20       x21       x22       x23	Counter 1 upper limit setting CNT1_H_VAL [7:0] Counter 2 upper limit setting CNT2_H_VAL[31:0] Counter 2 upper limit setting CNT2_H_VAL [23:16] Counter 2 upper limit setting CNT2_H_VAL [15:8] Counter 2 upper limit setting CNT2_H_VAL [7:0] Counter 3 upper limit setting CNT3_H_VAL[31:0] Counter 3 upper limit setting CNT3_H_VAL [23:16]	Can be read back
x1E x1F x20 x21 x22 x23	Counter 2 upper limit setting CNT2_H_VAL[31:0] Counter 2 upper limit setting CNT2_H_VAL [23:16] Counter 2 upper limit setting CNT2_H_VAL [15:8] Counter 2 upper limit setting CNT2_H_VAL [7:0] Counter 3 upper limit setting CNT3_H_VAL[31:0] Counter 3 upper limit setting CNT3_H_VAL [23:16]	Can be read back
x1F x20 x21 x22 x23	Counter 2 upper limit setting CNT2_H_VAL [23:16] Counter 2 upper limit setting CNT2_H_VAL [15:8] Counter 2 upper limit setting CNT2_H_VAL [7:0] Counter 3 upper limit setting CNT3_H_VAL[31:0] Counter 3 upper limit setting CNT3_H_VAL [23:16]	Can be read back Can be read back Can be read back Can be read back
x20 x21 x22 x23	Counter 2 upper limit setting CNT2_H_VAL [15:8] Counter 2 upper limit setting CNT2_H_VAL [7:0] Counter 3 upper limit setting CNT3_H_VAL[31:0] Counter 3 upper limit setting CNT3_H_VAL [23:16]	Can be read back Can be read back
x21 x22 x23	Counter 2 upper limit setting CNT2_H_VAL [7:0] Counter 3 upper limit setting CNT3_H_VAL[31:0] Counter 3 upper limit setting CNT3_H_VAL [23:16]	Can be read back
x22 x23	Counter 3 upper limit setting CNT3_H_VAL[31:0] Counter 3 upper limit setting CNT3_H_VAL [23:16]	
x23	Counter 3 upper limit setting CNT3_H_VAL [23:16]	Can be read back
	CNT3_H_VAL [15:8]	Can be read back
x24	Counter 3 upper limit setting CNT3_H_VAL [7:0]	Can be read back
x25	Counter 0 lower limit setting CNT0_L_VAL[31:0]	Can be read back
x26	Counter 0 lower limit setting CNT0_ L_VAL [23:16]	Can be read back
x27	Counter 0 lower limit setting CNT0_ L_VAL [15:8]	Can be read back
x28	Counter 0 lower limit setting CNT0_ L_VAL [7:0]	Can be read back
x29	Counter 1 lower limit setting CNT1_L_VAL[31:0]	Can be read back
x2A	Counter 1 lower limit setting CNT1_L_VAL [23:16]	Can be read back
x2B	Counter 1 lower limit setting CNT1_L_VAL [15:8]	Can be read back
x2C	Counter 1 lower limit setting CNT1_L_VAL [7:0]	Can be read back
x2D	Counter 2 lower limit setting CNT2_L_VAL[31:0]	Can be read back
x2E	Counter 2 lower limit setting CNT2_L_VAL [23:16]	Can be read back
x2F	Counter 2 lower limit setting CNT2_ L_VAL [15:8]	Can be read back
x30	Counter 2 lower limit setting CNT2_L_VAL [7:0]	Can be read back
x31	Counter 3 lower limit setting CNT3_L_VAL[31:0]	Can be read back
x32	Counter 3 lower limit setting CNT3_L_VAL [23:16]	Can be read back
x33	Counter 3 lower limit setting CNT3_L_VAL [15:8]	Can be read back
x34	Counter 3 lower limit setting CNT3_L_VAL [7:0]	Can be read back
x35	<u> </u>	D[7:0] The current count value of Counter 0, COUNT[31:24]
x36		D[7:0]

		The current count value of Counter 0, COUNT[23:16]
x37	Write address, clear interrupt	D[7:0] The current count value of Counter 0, COUNT[15:8]
x38	Counter reset control D [0]: counter 0 reset control D [1]: counter 1 reset control D [2]: counter 2 reset control D [3]: counter 3 reset control Write 1 to reset the corresponding counter	D[7:0] The current count value of Counter 0, COUNT[7:0]
x39	D [0]: counter 0 start-stop control 1: start, 0: stop	D[7:0] The current count value of Counter 1, COUNT[31:24]
x3A	D [0]: counter 1 start-stop control 1: start, 0: stop	D[7:0] The current count value of Counter 1, COUNT[23:16]
x3B	D [0]: counter 2 start-stop control 1: start, 0: stop	D[7:0] The current count value of Counter 1, COUNT[15:8]
x3C	D [0]: counter 3 start-stop control 1: start, 0: stop	D[7:0] The current count value of Counter 1, COUNT[7:0]
x3D	D [0]: digital I/O0 1: start, 0: stop	D[7:0] The current count value of Counter 2, COUNT[31:24]
x3E	D [0]: digital I/O01 1: start, 0: stop	D[7:0] The current count value of Counter 2, COUNT[23:16]
x3F	D [0]: digital I/O2 1: start, 0: stop	D[7:0] The current count value of Counter 2, COUNT[15:8]
x40	D [0]: digital I/O3 1: start, 0: stop	D[7:0] The current count value of Counter 2, COUNT[7:0]
x41		D[7:0] The current count value of Counter 3, COUNT[31:24]
x42		D[7:0] The current count value of Counter 3, COUNT[31:24]
x43		D[7:0] The current count value of Counter 3, COUNT[23:16]
x44		D[7:0] The current count value of Counter 3, COUNT[15:8]
x45		Counter 0 interrupt status D[0]:=1 overflow , =0 no overflow D[1]:=1 underflow, =0 no underflow D[2]:=1 upper limit, =0 no Upper limit D[3]:=1 lower limit, =0 no lower limit
x46		Counter 1 interrupt status D[0]:=1 overflow, =0 no overflow D[1]:=1 underflow, =0 no underflow D[2]:=1 upper limit, =0 no Upper limit D[3]:=1 lower limit, =0 no lower limit
x47		Counter 2 interrupt status

		D[0]:=1 overflow , =0 no overflow
		D[1]:=1 underflow, =0 no underflow
		D[2]:=1 upper limit, =0 no Upper limit
		D[3]:=1 lower limit, =0 no lower limit
x48		Counter 3 interrupt status
		D[0]:=1 overflow, =0 no overflow
		D[1]:=1 underflow, =0 no underflow
		D[2]:=1 upper limit, =0 no Upper limit
40		D[3]:=1 lower limit, =0 no lower limit
x49 x4A	Counter filter coefficient high 8-bit setting	Can be read back (unit: us) Can be read back (unit: us)
X4A X4B	Counter filter coefficient low 8-bit setting	Read back digital I/O status
X4D X4C		Read the address, latch all the counter
A le		values
X60		D[7:0]
		The current count value of Counter 4,
		COUNT[31:24]
X61		D[7:0]
		The current count value of Counter 4,
N/CO		COUNT[23:16]
X62		D[7:0]
		The current count value of Counter 4, COUNT[15:8]
X63		D[7:0]
1105		The current count value of Counter 4,
		COUNT[7:0]
X64		D[7:0]
		The current count value of Counter 5,
		COUNT[31:24]
X65		D[7:0]
		The current count value of Counter 5, COUNT[23:16]
X66		D[7:0]
100		The current count value of Counter 5,
		COUNT[15:8]
X67		D[7:0]
		The current count value of Counter 5,
		COUNT[7:0]
X68		D[7:0]
		The current count value of Counter 6, COUNT[31:24]
X69		D[7:0]
107		The current count value of Counter 6,
		COUNT[23:16]
X6A		D[7:0]
		The current count value of Counter 6,
		COUNT[15:8]
X6B		D[7:0]
		The current count value of Counter 6,
X6C		COUNT[7:0] D[7:0]
AUC		The current count value of Counter 7,
		COUNT[31:24]
X6D		D[7:0]
		The current count value of Counter 7,
		COUNT[23:16]
X6E		D[7:0]
		The current count value of Counter 7,

	COUNT[15:8]
X6F	D[7:0]
	The current count value of Counter 7,
	COUNT[7:0]
b1XXXXXXX	D [7:0] read back the ID
	Fixed 80H

Double-pulse Count: count the difference between A and B.

Single-pulse Count: count the rising edge and falling edge, B control the direction, 1: adding count,

0: reduction count.

Frequency Measurement: pulse format within a given time.